




INSTRUCTION MANUAL

3.2L HOT WATER DISPENSER



Model: SP-3202

Thank you for purchasing this appliance. Read all instructions carefully before use.

The important information, herein, is intended to prevent possible injuries and damage to the appliance. Please follow accordingly.

General Safety Precautions

- Always unplug appliance from the main electrical supply outlet before cleaning or when not in use.
- Always attach the power cord to the appliance BEFORE you plug it to the main electrical supply.
- To disconnect appliance, grasp the plug to remove, do not pull on the cord.
- Close supervision is necessary when operating appliance near children. Ensure the electrical cord does not hang over the work surface.
- Do not operate appliances with a damaged cord or plug. Any repairs should be done by an experienced technician or by an authorized service center.
- Always place appliance on a flat steady surface.
- When moving the appliance, be cautious and avoid touching hot surfaces.
- Do not immerse appliance or electrical parts in water or any other liquids.
- Use of accessories or equipment not supplied by the manufacturer may cause damage or malfunctioning of your appliance or result in injuries.
- Not suitable for outdoor usage or in damp areas. This appliance is for domestic use only.
- Do not dispense when boiling.
- Do not touch hot surfaces, use handles or knobs.
- Never block the stem vent opening.

The unit may not function properly if used in high elevation or in very cold or hot conditions. In such conditions, unit may keep boiling or not reach boiling point.

Proper Disposal




Products bearing the crossed out bin symbol are not to be disposed with your general household waste. For the correct collection and treatment of these products, take them to the collection points designated by your local authority. Alternatively contact the retailer who sold you the product.



Specifications

Model	SP-3202
Rated Voltage	120V~
Rated Power	700W
Frequency	60Hz
Capacity	3.2L

Parts Identification




Caution: Before use

1. Please read these instructions carefully before using and keep them for future reference.
2. Check and confirm the local main voltage is the same as stated on the appliance.
3. Handle power cord carefully. Do not bend or pull on cord. Unplug from wall socket when not in use.
4. Always use the dispenser in a vertical upright position.
5. Allow dispenser to cool before cleaning.
6. The unit may be deformed or damaged when exposed to heat or used in unstable surroundings (excess water or humidity.).
7. Boiling without any water in the pot would damage the unit.
8. Avoid touching the outer body during operation. Always allow unit to cool before handling.
9. Do not immerse power cord or unit in any water or any liquid.
10. Close supervision is necessary when appliance is used by or near children. Never leave appliance unattended.
11. Do not operate any appliance with a damaged cord or plug or malfunctions or has been damaged in any manner.
12. Do not attempt to repair the appliance, contact Sunpentown.
13. Never use attachments not recommended by the manufacturer.
14. The appliance is not intended for outdoor use or in damp areas. Household use only.
15. Power cord should not be tangled, left on hot surfaces or allowed to hang over table edges.
16. Appliance should be given ample air circulation on all sides.
17. An insulated hot pad is recommended on surfaces where heat may cause problems.
18. Do not use appliance for other than its intended usage.
19. Be cautious of hot steam when opening the top lid.

How To Use


Opening and Closing Top Lid

- To open: press down the Lid Lock with thumb and pull latch upwards. If unit was in operation, be cautious of hot vapor that may escape.
- To close: press lid down firmly. Make sure lid is securely closed or water will not reach set temperature and boil continuously. Make sure you hear a “click” when closing.



Removing and Replacing Top Lid

- To Remove: Lift top lid to about 45° angle, press the Release button (located at the rear of the top cover) and remove.
- To attach: press down on the Release button and place lid in the groove. Close lid firmly



Filling & Refilling

- Open the Top Lid and fill water with a separate container. Fill until the FULL mark is reached. Do not over fill as hot water may splash out during boiling.
- Close top cover, ensure lid is secured by pressing firmly down till “click” sound is heard.

Boil Water

Unit will begin to operate once power is connected. First attach power cord to unit’s receptacle then plug in to wall outlet.

- Do not open top cover while unit is in boiling process.
- Do not add water when appliance is in boiling process.
- Do not obstruct the top lid steam vent.

Dispensing Water

Press the UNLOCK button once (UNLOCK indicator light will illuminate) then press the DISPENSE button to dispense water.

- If the DISPENSE button is not pressed within 10 seconds after pressing the UNLOCK button, the unit will automatically revert back to LOCK position.
- The DISPENSE button will NOT operate if the unit's power is not connected.

Automatic water outlet lock

These safety features were included to ensure that hot water will not be dispensed should the DISPENSE button be accidentally depressed.

Re-boil Function

Press the "REBOIL" button to re-boil water in the pot back up to 212°F. After water re-boils, unit will switch to Keep Warm.

- Re-boil will not function if there is insufficient water inside the unit.
- Pressing the REBOIL button immediately after the water had just reached boiling point will have no effect, as the water is already at 212°F.

Auto Cut-Off

Appliance has the following safety features and will automatically shut off when:

- There is no water in the unit and unit boils dry.
- Power has been connected but no water added to unit.
- Water level is below the EMPTY mark.

Care and Cleaning

Disconnect power from wall outlet and allow appliance to cool before cleaning, remove cord from receptacle.

- Detach upper lid and pour out remaining water. Be cautious if water is hot.
- Do not wash under running water. Do not place in a dishwasher or dryer.
- Do not wet the control panel and receptacle.
- Do not leave water in pot unused for long period of time.
- Do not turn unit upside-down to dry.
- Do not immerse any part of the dispenser in water or any liquid.
- Do not use bleach, alcohol or other harsh chemicals
- Do not scrub with metal pads or sharp objects.
- Do not handle plug when hands are wet or damp.

Minerals in tap water may cause white residue to attach to the surface of the inner tank. They sometimes change the color of the inner tank (reddish or black). Clean the interior frequently to avoid this problem.

Lid and body

- Wipe clean with damp cloth.

Inner pot and inner lid

Use soft sponge to clean and rinse with water. The amount of build-up and stain depends on the quality of water and times of boiling. The inner pot should be cleaned once a month. If extremely dirty, use Citric Acid, lemon or lime juice:

- Add approximately 1 oz. of the preferred solution.
- Add water to the full line, close lid and connect power.
- Allow solution to boil and soak for 30~60 minutes.
- Dispense a few cups of solution to clean the piping.
- Disconnect power and allow unit to cool.
- Remove lid and pour out solution, rinse clean.
- If lemon was used, to remove the smell of lemon, fill with clean water, boil and dispose.
- DO NOT use: dish soap, scrubbing powder or brush, benzine, thinner or any harsh chemicals.

When not in use for an extended period of time, clean and let dry completely before storage. Store in original packaging or plastic bag and keep in a cool, dry place.

THIS APPLIANCE IS STRICTLY FOR DOMESTIC INDOOR USE ONLY.

Troubleshooting

SYMPTOM	POSSIBLE CAUSE
Water does not boil when plugged in. (Power LED on)	Dirty inner pot. Added water is already hot. Water level is below refill line.
Unit will not switch to Keep Warm	Unit may not function properly if used in high elevation or in very cold or hot conditions. In such conditions, unit may keep boiling or not reach boiling point.
Unit will not switch to Boil	Water level is too low. Dirty inner pot
Unit will not dispense or not dispensing smoothly	Unit not plugged in. Immediately after boiling, bubbles may form which makes it difficult to dispense. Open the lid to release steam. The interior is dirty and needs cleaning
Water is flowing out from unit	Water is filled above the FULL line.
White substance floating in water	These are mineral deposits. (Not erosion of inner pot.) Clean the unit according to the instructions under Maintenance
Boiling sound is excessively loud	Interior is dirty and needs cleaning.
Hot water has unpleasant odor or taste	Resin used in manufacturing may give off a mild odor. This will disappear with use. Due to chlorine in water – reboil the water



Your Guarantee

If this product is found to be faulty as a result of faulty materials or Workmanship within one year from date of purchase, it will be repaired free of charge.

This guarantee is subject to the following terms:

- Sunpentown must be notified of the fault.
- Proof of purchase must be presented to Sunpentown's nominated representative.
- The warranty will be void if the product is modified, misused or repaired by an unauthorized person.
- The warranty after repair will not be extended beyond the original one-year period.
- All replacement parts will be new or reconditioned.
- Parts, which are replaced, become the property of Sunpentown.
- The warranty applies for the use of the product in the USA only.

What is NOT COVERED:

- Warranty does not include freight charges.
- Incidental or consequential damage caused by possible defects with this product.
- Damage to product caused by improper power supply voltage, accident, fire, floods or acts of nature.
- Failure of product resulting from unauthorized modifications to the product.
- Improper installation or failure to perform the necessary maintenance.

This GUARANTEE is in addition to your Statutory Rights

Sunpentown Int'l Inc.
14625 Clark Ave, City of Industry, CA 91745
Tel: 1-800-330-0388
service@sunpentown.com · www.spt-usa.com